BULLETIN NO. 1141 ISSUE 1 JANUARY, 1948

TELETYPE

PRINTING TELEGRAPH SYSTEMS

PARTS

TELETYPE SEQUENTIAL CONTROL (SECO) SYSTEM EQUIPMENT



BULLETIN NO. 1141 ISSUE 1 JANUARY,1948

TELETYPE

PRINTING TELEGRAPH SYSTEMS

PARTS

TELETYPE SEQUENTIAL CONTROL (SECO) SYSTEM EQUIPMENT




ALPHABETICAL INDEX

APPARATUS CABINETS

DESCRIPTION	PAGE NO.	DESCRIPTION	PAGE NO.
Doors	1,2	Secondary Cabinet	1,2
Door Leader	2	Secondary Control Unit Shelf	23
Plug	2	Secondary Transmitter Distributor M	ounting
Primary Cabinet	1,2	Plate	_
Primary Transmitter Distributor She	lf 1,4	Secondary Transmitter Distributor S	
Receptacles	2	Separator	
Receptacle Cover	2	Slide - Left	
Receptacle Plate	2	Slide - Right	
Receptacle Side Cover	2	Strike	
Rectifier Platform	1	Strip - Left	
Roller (Assem.) Left	1	Switching Panel	
Roller (Assem.) Right	1	Tape Bin	
		Tape Bin	
	SEQUENTIAL	SELECTOR	
Blocking Levers - Primary (BSLA)	11	Pinion	13
Blocking Levers - Secondary (BS1B)-	27	Primary Blocking & Latching Levers (BSLA)	
Clutch Trip Lever	9	Primary Selector Panel ConnectorBlo	
Code Levers	5,6,14,26	Pull Bars	
Code Levers & Name Plates	5,6,14,26	Range Scale	
Contact (Assem.)	19	Secondary Blocking & Latching Lever	
Contact Levers	7	(BS1B)	27
Function Levers	5,26	Secondary Selector Panel Connector B	lock 19
Gears	13	Selector Main Shaft	13
Holding Magnet Selector	12	Selector Panel	16
Latching Levers - Primary	11	Sequential Selector (BSLA) 5	,6,7,8,9,10,11
Latching Levers - Secondary		Sequential Selector (BS1B)- 5,6,7,8	,9,10,11,26,27
Motor - Selector		Synchronous Motor	
Panel Counter Shaft	13	Transfer Levers	
		Terminal Block	5
	CONTROL	LUNITS	
Alarm Buzzer - Primary		Control Unit - Secondary	
Alarm Buzzer - Secondary		Cords & Plugs - Primary	
Condenser - Primary		Cords & Plugs - Secondary	*
Condenser - Secondary		Delayed Relay Timer - Primary	
Connection Block - Primary		Fusetron - Primary	
Connection Block - Secondary		Fusetron - Secondary	
Control Unit - Primary	17,18,19,20,21	Line Relay Base & Filter - Primary-	18,19


CONTROL UNITS (Continued)

DESCRIPTION	PAGE NO.	DESCRIPTION PAGE NO.
Line Relay Bracket (Assem.) Secondary -	28,30	Resistors - Primary 19
Line Jack Strip - Primary	1,9	Resistors - Secondary 28,30
Line Jack Strip - Secondary	19,29	Slip Connection - Primary 21.28
Push Button & Switch - Primary	17	Terminal Block - Primary 4,18,21
Push Button & Switch - Secondary	28	Terminal Block - Secondary 21,29
Relays - Primary	18,20	Toggle Switch - Primary 17
Relays - Secondary	29	Toggle Switch - Secondary 28,30
. MULTIP	LE TRANSMITTER	DISTRIBUTOR SET
Base (Bottom View)	38	Motor Cover (Assem.) 39
Base Plate (Assem.)	32,36	Motor - MXB 40
Base (Top View)	- 37	Multiple Transmitter Distributor - MFD1 32,33
Cam Sleeve & Shaft (Assem.) - MFD1	33	Multiple Transmitter Distributor - MXD14-34, 35, 36
Cam Sleeve & Shaft (Assem.) - MXD14	35	Multiple Transmitter Distributor Base -
Connection Block		MXB 37,38,39,40
Contact Lever (Assem.)	33,35	Plug (Assem.) 39
Detent Bracket (Assem.)	32	Resistors 38
Filter (Assem.)	33,34	Release Bar Contact (Assem.) 35
Gears		Selector Lever (Assem.) 35
Magnets		Top Plate 34,39



(Front View)


All parts shown on this page are common to Primary and Secondary Single and Double circuit Cabinets unless otherwise specified.



APPARATUS CABINET


(Rear View)


All parts shown on this page are common to Primary and Secondary single and double circuit cabinets unless otherwise specified.




TRANSMITTER DISTRIBUTOR SHELF
(PRIMARY)


(B-1141)









SEQUENTIAL SELECTOR (BSIA) RIGHT SIDE (TOP VIEW)



SEQUENTIAL SELECTOR (BSIA) CENTER SECTION LEFT SIDE (TOP VIEW)




4




SEQUENTIAL SELECTOR (BSIA) BOTTOM SECTION LEFT SIDE (TOP VIEW)

*





SEQUENTIAL SELECTOR (BSIA) BOTTOM SECTION RIGHT SIDE (TOP VIEW)




PRIMARY BLOCKING AND LATCHING LEVER ASSEM (BSIA)

•





(TOP VIEW)




PANEL COUNTER SHAFT




SUPPLIED WITH EQUIPMENT

,	CODE LEVERS & NAME PLATES SUPPLIED WITH EQUIPMENT													
CHARACTER	A	В	С	D	Ε	F	G	н	- 1	J	к			
CODE LEVER (WITH NAME PLATE)	115000	115001	115002	115003	115004	115005	115006	115007	115008	115009	115010			
NAME PLATE NUMBER	115066	115067	115068	115069	115070	115071	115072	115073	115074	115075	115076			
CHARACTER	L	м	N	0	Р	Q.	R	s	т	U	v			
CODE LEVER (WITH NAME PLATE)	115011	115012	115013	115014	115015	115016	115017	115018	115019	115020	115021			
NAME PLATE NUMBER	115077	115078	115079	115080	115081	115082	115083	115084	115085	115086	115087			
CHARACTER	w	x	Y	z	LF	SP	CR	BL	FIG	LET	NO CODE			
CODE LEVER (WITH NAME PLATE)	115022	115023	115024	115025	115026	115027	115028	115029	115030	115031	115032			
NAME PLATE NUMBER	115088	115089	115090	115091	115092	115093	115094	115095	115096	115097	115098			




	CODE L	EVERS 8	NAME	PLATES	TO BE S	UPPLIED	ON REP	LACEMEN	IT ORDER	RS	
CHARACTER	A	8	С	D	E	F	G	н	ı	J	к
GODE LEVER	117450	117451	117452	117453	117454	117455	117456	117457	117458	117459	117460
NAME PLATE NUMBER	115066	115067	115068	115069	115070	115071	115072	115073	115074	115075	115076
CHARACTER	L	м	N	0	Р	Q	R	s	т	U	v
CODE LEVER	117461	117462	117463	117464	117465	117466	117467	117468	117469	117470	117471
NAME PLATE NUMBER	115077	115078	115079	115080	115081	115082	115083	115084	115085	115086	115087
CHARACTER	w	×	Y	z	LF	SP	CR	BL	FIG	LET	NO CODE
CODE LEVER	117472	117473	117474	117475	117476	117477	117478	117479	117480	117481	115032
NAME PLATE NUMBER	d 15088	115089	115090	115091	115092	115093	115094	115095	115096	115097	115098



82283 SYNCHRONOUS MOTOR, I 40 H.P. IIOV., 60 CYCLE A.C. (G.E. MODEL 5SH25ABIIB)
(DOES NOT INCLUDE PARTS MARKED (A))


MU 36 MOTOR UNIT (INCLUDES 82283 MOTOR AND PARTS MARKED (A))

(B-1141)




SELECTOR PANEL


All parts shown are common to Primary and Secondary Selectors




FRONT PANEL
PRIMARY CONTROL UNIT (CU1)




PRIMARY CONTROL UNIT (CU1)







PRIMARY RELAY CHART											
IDENTIFICATION NUMBER	A	В	С	BI	CI	82	C2	83	сз	B4	C4
RELAY (ASSEM.) NUMBER	115326	115326	115326	115326	115326	115326	115326	115326	115326	115326	115326
IDENTIFI CATION NUMBER	85	C5	D	Et	E2	R6	R5	R4	R3	R2	RI
RELAY (ASSEM.) NUMBER	115326	115326	115326	115335	115335	115354	115329	115332	115328	115331	116331


RELAYS AND ASSOCATED PARTS (PRIMARY CONTROL UNIT)









115310 CORD (ASSEM.) (APPROX. 38" LONG)




115311 CORD (ASSEM.) (APPROX. 28"LONG) 115349 CORD (ASSEM.) (APPROX. 38" LONG)




115342 CORD (ASSEM) (APPROX.50"LONG)




(PRIMARY CONTROL UNIT)




CONTROL UNIT SHELF (SECONDARY)




TRANSMITTER DISTRIBUTOR SHELF (SECONDARY)



TRANSMITTER DISTRIBUTOR MOUNTING PLATE (ASSEM.)
(SECONDARY)




SEQUENTIAL SELECTOR (BSIB) LEFT SIDE (TOP VIEW)




PARTS NOT LISTED ARE SAME AS BSIA (SEE PAGE II) 115249 CABLE-W.D. 2470

SECONDARY BLOCKING AND LATCHING LEVER ASSEM (BSIB)




SECONDARY CONTROL UNIT (BOTTOM VIEW)

All parts shown on this page are common to CU2 and 3 unless otherwise specified.




(TOP VIEW)


All parts shown on this page are common to CU2 and 3 unless otherwise specified.



(FRONT VIEW)



(RIGHT END VIEW)




115357 CORD (ASSEM.) - (APPROX.52"LONG) 115360 CORD (ASSEM.) - (APPROX.39"LONG)




115365 CORD (ASSEM.)- (APPROX. 30"LONG)



115366 LINE CORD (ASSEM.) - (APPROX. 65"LONG)





115388 CORD (ASSEM.) - (APPROX. 57"LONG)




115389 CORD (ASSEM.) - (APPROX.57"LONG)

CORDS & PLUGS (SECONDARY CONTROL UNIT)








115433 BRACKET

104702 SCREW 3640 LOCK WASHER


||544| FILTER (ASSEM.)-




RELEASE BAR CONTACT (ASSEM.)


74554 SPRING POST








BASE (BOTTOM VIEW)





82283 SYNCHRONOUS MOTOR, 1/40 H.P.110 V., 60 CYCLE A.C. (G.E.MODEL 5SH25AB11B) (EXCLUDES PARTS MARKED (A)

M-207	Magnet Coil - 92 Ohms, 12	3438	Washer, 11, 15, 16, 18, 23, 36, 37	46094	Company 18 32 - 7/1/1 01
M-224	Magnet Coil - 450 Ohms, 32, 36	3598	Nut (6-40 Hex.), 1, 2, 3, 4, 5,	49420	
MU36	Motor Unit, 15		9, 10, 11, 12, 24, 25, 32, 33, 34,	49653	
W-6104.	Nut (5/32-36 Hex.), 15,40		35, 36, 39	55090	Spring, 5, 6, 26, 35, 36
W-10074	Washer, 13	3599	Nut (4-40 Hex.), 12, 34, 35, 36,	70314	Washer, 3
W-10086	Lock Washer, 16		37	74097	Nut (5/16-32 Hex.),37
33-2	Screw (6-32 x 3/8),29	3606	Nut (6-40 Hex.), 12, 19, 21, 23,	70803	Screw (6-40 Pivot), 34
33-15	Screw (2-56 x 1/8),11		29, 30, 32, 34, 36, 37	71015	Buzzer, 21
33-86	Screw (4-40 x 1/8),19	3610	Spring, 7	71073	Washer, 12
33-158	Screw (6-40 x 1/2), 32, 36	3640	Lock Washer, 3, 6, 7, 10, 11, 12,	71505	Oil Wick - Felt, 13
33-179 33-193	Screw (8-32 x 3/8),3		13, 19, 24, 25, 32, 33, 34, 35,	71697	
33-197	Screw (6-32 x 1),2 Screw (6-40 Shoulder),3,23	2616	36, 37	71858	Washer, 15
33-198	Screw (6-40 x 1/4 Set),1,2,3,	3646	Lock Washer, 23	71976	
22-270	13,23,24	4703 4708	Spring, 36	72096	
33-208	Screw (10-32 x 1/2),25	4614	Spring, 5, 6, 12, 26	72263	Post,9
33-280	Screw (2-56 x 3/16),39	4843	Lock Washer, 3, 13, 37 Stiffener - Upper, 33, 35	72508	
33-282	Screw (10-32 x 1/2),17	4844	Stiffener - Lower, 33, 35	72514	Spring, 13
34-4	Nut (10-32 Hex.)1,2,4,18,19,	5446	Screw (4-40 x 9/16), 10, 32, 34	72515 72517	
	21,25,29	5475	Nut (3/16-40 Hex.),12	1471	Nut (5/16 x 32 L.H. Hex. Keyed),13
34-11	Nut (2-56 Hex.)33,35,39	5599	Nut (8-32 Hex.), 23, 25	72521	Oil Wick - Felt,13
34-56	Nut (4-40 Hex.), 12	6390	Screw (6-40 x 3/16),5	72563	Washer - Felt, 13, 33, 35
34-58	Nut (10-32 Hex.), 17, 18, 21, 25	6685	Sword, 12	72565	Lock Washer, 13
35-70	Spring, 11, 27, 36	6689	Separator Plate, 12	72579	Washer, 3, 37
61-24	Washer - Bakelite, 19,30	6745	Screw (10-32 x 1/2),11,16,	72644	Ball Bearing, 13
103-27 123-244	Washer, 6, 19, 32, 34, 35, 36 Washer, 12	6716	38,39	73235	Screw (6-40 x 7/8),32
	Washer, 36	6746	Screw (6-40 x 5/16), 5, 7, 8, 9,	73572	
1026	Sorew (6-40 x 3/8),21,33,35,		10,11,12,13,15,16,19,29,32,		Washer, 36
2020	36,37	6799	33, 35, 36, 40	74032	Washer, 24
1028	Screw (4-40 x 1/4),36	6801	Screw (6-40 Shoulder),12 Screw (4-40 Pilot),12	74059	
1030	Screw (6-40 Shoulder), 12, 24	6810	Screw (10-32 x 3/8),13,15,	74100 74171	
1038	Screw (6-40 x 9/32),11		16,18,19,23,29,37	74283	Screw (6-40 Eccentric), 34 Washer, 24
1043	Screw (10-32 x 5/16).18.19.20	6811	Screw (6-40 x 5/8), 4, 12, 16,	74367	Screw (10-32 x 1 7/16),18
1050	Screw (6-40 x 7/32),33		37	74399	Screw (6-40 Pilot),12
1160	Screw (6-40 x 5/16).37.38.39	6827	Connection Block (with 1064	74536	Screw (6-40 x 5/32),34
1064	Screw (6-32 x 1/4),30		Screw),30	74554	Spring Post, 32, 35, 36
1073	Screw (6-40 Thumb), 12	6909	Stop Lever, 12	74567	Sorew (1/4-20 x 33/64),15,40
1093	Screw (8-32 x 7/16),25	6966	Eccentric Stop, 12	74614	Resistor - 2600 Ohms (2000-
1104	Screw (10-32 Thumb),13	7001	Washer, 12		600),30
1121 1159	Screw (10-32 x 3/8),25	7002	Washer, 2, 3, 4, 5, 10, 11, 12, 13,	74615	Resistor (2000 unms), 30
1160	Sorew (4-40 x 3/8),11 Sorew (6-40 x 5/16),4,8,13,18		18,19,23,24,25,29,30,32,34,		
1161	Screw (6-40 x 1/4) 32 33 36	7007	36, 37, 38, 39	74716	Bushing, 19
1162	Screw (6-40 x 1/4), 32, 33, 36 Screw (4-40 x 1/4), 6, 11, 21, 34,	7027	Trip Plunger, 12	74722	Washer, 12
	35,36	7318	Roller, 32, 36	74805	Screw (10-32 x 3/4),16,19,37
1163	Screw (4-40 x 3/16),11,19,32,	7345	Contact Lever, 33, 35 Screw (10-32 Shoulder), 1	74891 74900	Shim004 Thick,10
	33,36	7386	Stud, 32, 36	74965	Washer, 37 Spacer, 19
1164	Screw (2-56 x 3/16), 36	7389	Driving Clutch 22 25	74986	Screw (6-40 x 13/32),5
1167	Screw (6-40 x 3/4), 35 Screw (4-40 x 5/16), 35	7391	Driven Clutch, 33, 35	75231	Bushing, 19
1168	Screw (4-40 x 5/16),35	7415	Driven Clutch, 33, 35 Nut (1/2-32 Hex.),13 Spring,12 Spring,12 Collar,12 Spring,12	75435	Resistor (600 Ohms),30
1169	Sorew (6-40 x 7/16),2,13,36	7602	Spring, 12	75606	Spring, 33, 35
1172 1176	Screw (2-56 x 5/16), 33, 35 Screw (6-40 x 3/16), 5, 13, 15, 19	7603	Spring, 12	75607	Washer, 33, 35
11/0	23,25,29,30,33,38,39	7607	Collar, 12	75750	Washer - Bakelite, 19, 30
1179	Sorew (6-40 x 5/8),40	7614 7654	Spring, 12 Shim .004 Thick, 33, 35 Screw (4-40 Special), 34	76099	Washer, 23
1196	Screw (6-40 Shoulder),32	7678	Screw (4-40 Special),34	76167	Screw (4-40 x 3/16),34
1206	Screw (4-40 x 9/16),19,37	7679	Roller, 34	76168 76236	Screw (6-40 x 3/16),18
1208	Screw (10-32 x 5/8),1,18	7825	Spring, 8	76260	Nut (5/16-18 Hex.),3
1214	Screw (10-32 x 5/8),1,18 Screw (10-32 x 13/32 Set),17	8157	Selector Lever - Right, 12	76379	Screw (6-40 Shoulder), 34 Spring, 36
1223	Screw (10-32 x 1/2),4,16	8158	Selector Lever - Left, 12	76461	Spacer, 16
1268	Screw (9/64-40 x 5/16),19,36	8254	Clamp, 29	76484	Fan, 15, 40
1269	Screw (6-40 x 1/2),21,37	8330	Washer, 5, 29	76532	Bushing, 34
1297	Screw (6-40 x 2 7/16), 19, 30	8333	Screw (10-32 x 3/8),18	77201	Spacer, 4
2191	Lock Washer, 1-13, 15, 16, 18, 19,	8539	Screw (6-40 x 1/2),8,13,16	77348	Receptacle, 2
2201	21,23,24,25,29,30,32-40 Nut (5/16-32 Hex.),9,10,13	8543	Screw (6-40 x 1/4),1,2,6,19,		Screw (4-40 x 3/16),15,40
2254	Washer, 3	8896	34, 35, 36, 38, 39	78163	Post, 12
2322	Lock Washer, 16,23	9558	Shim004 Thick, 32, 34, 36	78164	Selector Post, 12
2382	Lock Washer, 17, 18, 19, 20, 21	9559	Contact Spring - Long, 33, 35 Contact Spring - Short, 33, 35	78281	Name Plate, (Teletype), 39
2415	Spring, 9	9649	Contact Stop - Lower, 33, 35	78596	Screw (10-32 x 5/8),8,37 Washer,12
2438	Washer, 36	9655	Contact Stop - Upper, 33, 35	78597	Screw (10-32 Shoulder),12
2449	Lock Washer, 15, 25, 40	22746	Spring, 9	79523	Screw (2-56 x 25/32),19
2481	Washer, 32	31636	Spring.9	80283	Screw (4-40 Shoulder),36
2526	Spacing Collar - 5/32 Thick,	34432	Washer. 1. 2. 3. 8. 12. 19. 24	80299	End Play Spring, 15,40
2//2	33-35	34826	Washer, 18 Washer, 21 Washer, 29 Washer, 34 Contact Spring, 35 Plate, 19, 35	80309	Washer - Felt, 15, 40
2663	Buffer - Rubber, 32, 37	35826	Washer, 21	80310	Washer - Felt, 15, 40
2669	Lock Washer, 1, 2, 3, 4, 8, 10, 11,	41663	washer, 29	80311	Washer, Cupped, 15.40
	12, 13, 15, 16, 18, 19, 21, 23, 24,	41675	wasner, 34	80312	Washer, 15, 40
2760	25, 29, 32, 36, 37, 38, 39 Spring, 16	41720 41732	Plate 10 25	80313	Washer, 15, 40
2846	Washer, 23, 25, 40	41733	Plate, 19, 35 Insulator, 19, 35	80334	Terminal, 19
3292	Nut (1/4-20 Hex.),25	42661	Spring, 13	80342	Screw (6-40 x 23/64),7,8,9,
3298	Eccentric, 37	44035	Screw (10-32 x 9/16), 32, 36,	80358	16,25 Ball Bearing,15,40
3339	Nut (9/16-32 Hex.),13		37	80444	Screw (6-40 x 1/4),8,9,10,
3340	Lock Washer, 13	44048	Washer, 4, 30	- >	12,13,16,18,25,32,36,38
3354	Nut (8-32 Hex.),3,24	45969	Screw (10-32 x 3/4),1,2	80471	Spring, 33, 35

	Spring Post, 35 Screw (4-40 x 25/32),19 Plug,2 End Shield (with 80754 Oiler), 15,40 Washer, 12 Oiler, 15,40 Screw (6-40 x 1 7/16),4 Screw (4-40 x 1/4),34 Terminal, 35 Washer, 18 Resistor (8000 Ohms), 30 Condenser (1/100 MF),19 Condenser, 1/4 MF,18 Synchronous Motor, 1/40 H.P., 110 V. 60 Cycle A.C. (G.E.					
80478	Spring Post, 35	90815	Resistor (5000 Ohms),30	100663	Socket,19	
80508	Screw (4-40 x 25/32),19	90905	Post, 12	101385	Spring, 36	
80542	Plug, 2	91120	Spring, 12	101386	Spring, 34	
80558	End Shield (with 80754 Oiler),	91682 1	Receptacle,2	101591	Wick - Felt, 32, 36	
dono.	15,40	92175	P1n, 34	101766	Cam Sieeve (Assem.), 35	
80721	Washer, 12	92273 1	Screw (2-70 x 1/4/,20	102052	Poil - Bight (Black High	
80851	Samew 16-40 x 1 7/16) 4	92291	Condenser (1/10 MF).19	TOTO IDA	Gloss).25	
80057	Sorew (b=60 x 1/b) 3b	92309	Resistor (ACO Ohms).19	102069BA	Rail - Left (Black High	
81726	Terminal. 35	92685	Spacer. 36		Gloss),25	
81774	Washer, 18	92748	Screw (6-40 x 1 7/16),19,30	102180	Screw (6-40 x 1 15/16),30	
81775	Resistor (8000 Ohms), 30	92787	Spacer, 36 Screw (6-40 x 1 7/16), 19, 30 Eccentric, 16 Toggle Switch, 28 Washer, 16 Armature, 36 Washer, 37	102774	Bolt (8-36 x 4 3/8),15,40	
81825	Condenser (1/100 MF),19	93136	Toggle Switch, 28	102839	Washer, 34	
81841	Condenser, 1/4 MF, 18	931.63	Masner, 10	102001	Tatch 34	
0440)	110 V, 60 Cycle A.C. (G.E.	93966	Washer, 37	102942	Plate, 34	
	M-4-3 (CTT2(AD33D) 16 (O	01.670	Condensor 1/10-1/10-1/100 MP	102081	Samew (1/L=20 x 1/2) 1 2 L	
82440	Screw (6-40 x 7/16), 6, 8, 12		38	102141	Fusetron - 10 Amp., 18	
82474	Terminal, 19, 22, 31, 33	94707	Insulator, 15,40	103284	Fusetron - 3.2 Amp., 18,29	
82702	Screw (6-40 x 9/32),18 Rotor (Assem.),15,40 Rotor (Assem.),15,40	95003	Receptacle, 2	103286	Crommet - Pubber 15 40	
82840	Rotor (Assem.),15,40	95064	Plug = / Prong. 22. 31	103539	Sorew (6-40 x 3/8),5,32,36,	
82841		95937	Condenser 1/100 MF, 30, 33, 34	///	37	
82843	Spring, 15, 40	95938	Condenser 1/10 MF, 30, 33, 34	104082	Screw (1/4-20 x 3/8),23	
82845	Washer, 15, 40	96258	Wire - Black (3" Long), 19	104702	Screw (4-40 x 7/16),34	
82848	Brush Holder (with Brush),	96261	Wire - Black (3 3/4" Long),19	104705	Ball Bearing, 13	
90950	15,40	97290	Screw (10-32 x 5/16),2,3,23,24	104524	Sheft 11	
82850	End Shield (With 80/54 Olier),	97393	Screw (6-40 Shoulder).11	105634	Roller, 34	
83496	Sorew (8-32 x 5/16).2	97501	Side Frame - Right (with	107393	Toggle Switch, 17, 28	
83561	Washer - Spring, 3	,,,,	Bushing), 35, 36	108010	Screw (6-40 x 1/8),19	
83856	Screw (4-40 x 11/16),35	97503	Side Frame - Left (with	108215	Condenser 1/4 MF, 30	
83871	Screw (10-32 x 5/16),16,18	0050/	Bushing),35,36	108352	Screw (6-40 x 3/8),30	
83885	Nut (6-32 Hex.),23	97506	Shart, 33, 35	109899	Directing Dail 13	
81666	Contest Spring 35	97513	Shaft. 36	110653	Post. 36	
81,705	Contact Spring, 35	97514	Selector Lever Bail, 36	110739	Bracket,19	
84892	Stiffener, 35	97515	Bail Extension, 36	110777	Detent Spring, 34, 36	
84990	Screw (.138-40 x 1/4),33	97516	Bushing, 36	110778	Bracket, 34	
85935	Spring Post, 16	97523	Tape Out Lever, 36	110780	Tape Retaining Lid, 34	
86458	Screw (1/4-20 x 1),25	97525	reed Pawi Lever, 30	110781	Ton Plate 34	
86713	Nut (4-40 X 5/10),15,40	97527	Feed Pawl. 36	110824	Screw (6-40 x 2).38	
871.77	Resistor (1000 Ohms), 30	97528	Retainer. 36	110869	Pinion - 19T,13	
87638	Sorew (2-56 x 3/32),11	97529	Clutch Lever, 32, 36	110870	Gear - 42T,13	
88879	Brush Holder Support, 15,40	97537	Contact Lever, 35	110955	Cardholder, 39	
89405	Bushing, 15, 40	97538	Lever, 35	111048	Receptacie, 31	
89406	Washer - Spring, 15, 40	97540	Shart, 33, 35	111363	Spring 32 36	
89407	Otter Pin, 15, 20, 40	97542	Magnet Yoke, 32, 36	111442	Screw (4-40 Shoulder).36	
89896	011er.32.36	97543	Bracket, 36	111464	Shim004 Thick, 32, 36	
89897	Nut (10-32 Hex.), 32, 36	97545	Latch, 36	111647	Resistor - 1000 Chms, 38	
89963	Eccentric, 1, 2,	97546	Bracket, 36	112539	Ber, 32	
89969	Washer - Bakelite, 19, 30	97547	Contact (Assem.), 37	112541	Contact Bracket 33.35	
90024	Armeture Bracket 12	97549	Release Bar. 35	112542	Bushing - Bakelite, 33, 35	
90069	Detent Post.12	97550	Stud.35	112543	Cover Plate, 33, 35	
90088	Trip Latch, 12	97551	Stud, 35	112544	Screw (2-56 x 3/4),33,35	
90096	Washer, 38	97554	Bracket, 34	112545	Insulator, 33, 35	
90247	Resistor (3410 Ohms),19	97555	Process - Bight 34	1125.7	Stiffener - Short 33.35	
90248	Wound States (with Been) 15 40	97557	Detent Lever. 34	112548	Stiffener - Long. 33.35	
90265	Screw (6-40 Special).12	97583	Bushing, 32, 36	112829	Bushing, 8	
90427	Resistor - 3400 Ohms (1400-	97908	Spacer, 37	112926	Socket, 17, 28	
	2000),30	98361	Shims .005 Thick, 33, 35	112927	Cap - Amber, 17, 28	
90505	Locking Lever, 12	98613	Spring, 35	112928	Lamp = Neon, 17, 28	
90507	Separator Top Plate, 12	90042	Selector Lever #1.36	113167	Slip Connection Block, 21, 25	
90508	Detent 12	99260	Selector Lever #2.36	113168	Insulating Strip, 25	
90510	Spring, 12	99261	Selector Lever #3,36	113169	Retaining Strip, 25	
90511	Screw (6-40 x 1/2),12	99262	Selector Lever #4,36	113174	Insulation Strip,21	
90512	Selector Arm Bracket, 12	99263	Selector Lever #5,36	113175	Serew (t-t0 = 3/8) 21 25	
90513	Eccentric, 12	99278	Sorew (6-40 Shoulder), 32, 30	113181	Spring - Right, 21, 25	
90514	Sorew (3/16-40 Pivot),12	99309	Resistor - AOO Ohms. 30	113182	Spring - Left, 21, 25	
90516	Selector Arm. 12	99744	Resistor - 8000 Ohms, 19	113183	Insulator, 21, 25	
90517	Spring, 6, 12	99802	Plate, 19	113184	Spring, 32, 34	
90518	Locking Wedge, 12	99803	Insulator, 19	113185	Spring, 32, 34	
90519	Screw (2-56 x 5/32),12	99804	Insulator, 19	113100	Recentacle 29	
90520	Armature Lever, 12	99806	Bracket 19	113243	Spacing Collar - 9/32	
90539	Bushing, 35	99807	Spring, 19		Thick, 33	
90679	Washer, 39	99809	Spring, 19	113373	Mounting Block, 21	
90759	Armature Bracket Link, 12	99816	Relay Base, 19	113956	Selector Plate, 12	
90774	Bell Crank, 12	100108	Nut (4-40 Hex.), 21	114318	Mount - Vibration 16 25 38	
90776	Spring, 19, 40 Washer, 15, 40 Brush Holder (with Brush), 15, 40 Screw (8-32 x 5/16), 2 Washer - Spring, 3 Screw (4-40 x 11/16), 35 Screw (10-32 x 5/16), 16, 18 Nut (6-32 Hex.), 23 Bushing, 35 Contact Spring, 35 Contact Spring, 35 Contact Spring, 35 Stiffener, 35 Screw (1/4-20 x 1), 25 Screw (1/4-20 x 1), 25 Screw (1/4-20 x 1), 25 Screw (4-40 x 5/16), 15, 40 Nut (4-40 Hex.), 13 Resistor (1000 Ohms), 30 Screw (2-56 x 3/32), 11 Brush Holder Support, 15, 40 Washer - Spring, 15, 40 Cotter Pin, 15, 28, 40 Oil Wick - Felt, 13, 32, 36 Ciler, 32, 36 Nut (10-32 Hex.), 32, 36 Eccentric, 1, 2, Washer - Bakelite, 19, 30 Coil Retainer, 12 Armature Bracket, 12 Detent Post, 12 Trip Latch, 12 Washer, 38 Resistor (3410 Ohms), 19 Resistor (5610 Ohms), 19 Resistor (5610 Ohms), 19 Wound Stator (with Base), 15, 40 Screw (6-40 Special), 12 Resistor - 3400 Ohms (1400- 2000), 30 Locking Lever, 12 Separator Top Plate, 12 Spring, 12 Sorew (6-40 x 1/2), 12 Sclector Arm Bracket, 12 Eccentric, 12 Screw (3/16-40 Pivot), 12 Sclector Arm, 12 Spring, 6, 12 Locking Wedge, 12 Screw (2-56 x 5/32), 12 Armature Lever, 12 Screw (2-56 x 5/32), 12 Armature Bracket Link, 12 Bushing, 35 Washer, 39 Armature Bracket Link, 12 Bushing, 35 Washer, 12, 36	100658	Plug. 15	115000	A Code Lever (with Name	
30/91	2002 " " " 12, 30	2000,0			Plate),14	

115001 B Code Levers (with Name	115090 Y Name Plate 14	115206 Procedure 5
Plate),14	115091 Z Name Plate.14	115207 Prenefer Lever #1 12
Distal I	115092 LF Name Plate, 14	115208 Transfer Lever #1,12
115003 D Code Towns (with Many	115093 SP Name Plate, 14	115209 Transfer Lever #3 12
Plate) 1	115094 CR Name Plate, 14	115210 Transfer Lever #4,12
115004 E Code Tevere (with Name	115095 BL Name Plate, 14	115211 Transfer Lever #5 12
Plate 1 1.	115096 FIG Name Plate, 14	115212 Comb. 5
115005 F Code Levens (with Many	115097 LET Name Plate, 14	115213 Nut (4-40 Hex.) 7 11
Plate 1 14	115098 (No Code)	115214 Screw (4-40 x 3/32).7.11
115006 G Code Levers (with Name	115102 Stop Bar,7	115215 Bracket - Right, 10
Plate). 14	115103 Bar, 7	115216 Clutch Trip Shaft.9
115007 H Code Levers (with Name	115104 Spring Bar, 7	115217 Screw (5/16-32 Pivot).9
Plate), 14	115106 Chaft 11	115218 Clutch Trip Lever. 9
115008 I Code Levers (with Name	115107 Cotton Din 6 0 13	115219 Blocking Lever, 10
Plate).14	115108 Bow 8	115220 Eccentric, 10
115009 J Code Levers (with Name	115100 Spring Pop 2	115221 Washer - Felt,9
Plate),14	115110 Comb. 8	115222 Detent Post,8
115010 K Code Levers (with Name	115111 Block 8	115223 Post, 8
Plate),14	115112 Comb. 7	115225 COMB,5
115011 L Code Levers (with Name	115113 Guide, 7.8	115227 More Diet - 33
Plate),14	115114 Bracket - Right, 10	115220 Detent James d
115012 M Code Levers (with Name	115116 Bracket - Left.9	116231 Duch Dom 5
Plate), 14	115117 Bar, 10	115232 Cam Cleave 13
11)01) N Code Levers (with Name	115118 Driving Link - Left. 10	115233 Socket 19
115014 O Code Lemans during to	115119 Bracket - Left, 9	115234 Roil Support - Dicht 16
Plata) 1	115120 Link,9	115235 Rail Support - Left 16
115015 P Code Larena (with Your	115121 Screw (6-40 Shoulder),9	115236 Drawer Slide - Right 16
Plete) 1	115122 Washer - Felt,9	115237 Drawer Slide - Left. 16
115016 0 Code Levene (with News	115125 Stripper Bail (with Post), 9	115238 Bracket.16
Plate),14	115090 Y Name Plate, 14 115091 Z Name Plate, 14 115092 LF Name Plate, 14 115093 SP Name Plate, 14 115094 CR Name Plate, 14 115095 BL Name Plate, 14 115096 FIG Name Plate, 14 115096 FIG Name Plate, 14 115098 (No Code) 115102 Stop Bar, 7 115103 Bar, 7 115104 Spring Bar, 7 115105 Bracket, 6, 8 115106 Shaft, 11 115107 Cotter Pin, 5, 8, 11 115108 Bar, 8 115110 Comb, 8 115111 Block, 8 115112 Comb, 7 115113 Guide, 7, 8 115114 Bracket - Right, 10 115116 Bracket - Left, 9 115117 Bar, 10 115118 Driving Link - Left, 10 115119 Bracket - Left, 9 115120 Link, 9 115121 Screw (6-40 Shoulder), 9 115122 Washer - Felt, 9 115125 Stripper Bail (with Post), 9 115127 Latch (with Post), 10 115128 Stripper Plate Arm - Left (with Post), 9 115129 Stripper Plate Arm - Left	115239 Strap, 16
115017 R Code Levers (with Name	115128 Stripper Plate Arm - Left	115240 Latch - Right, 16
Plate),14	(With Post), 9	1152Ll Forentwin 16
115018 S Code Levers (with Name		115242 Latch - Left.16
Plate),14	AAJIJV BORCHP. IU	115243 O11 Pan.16
115019 T Code Levers (with Name	115133 Screw (5/16-32 Pilot),10 115134 Washer - Felt,10	115244 Bar Lower - Front, 16
Plate), 14		115245 Bar - Lower,16
115020 U Code Levers (with Name	115136 Driving Link - Bight 10	115246 Bar - Lower and Upper -
Plate),14	115136 Driving Link - Right, 10 115138 Link, 9	Right,16
115021 V Code Levers (with Name	115139 Bracket 10 ·	115247 Bar - Upper,16
Plate),14	115140 Ball Bearing Lock, 13	115248 Guide Plate - Upper and
115022 W Code Levers (with Name	115141 Screw (6-40 Shoulder) 13	Lower, 16
Plate, 14	115142 Main Shaft.13	115250 Motor Gunnant 16
115023 X Code Levers (with Name	115143 Ratchet Hub. 13	115251 Bon 16
Plate, 14	115146 Sleeve.13	115252 Chring Been 14
115024 Y Code Levers (with Name	115147 Drive Arm, 13	115253 Spring 16
Plate, 14	115148 Disc,13	115254 Bracket - Bight 10
115025 Z Code Levers (with Name	115149 Eccentric, 13	115255 Screw (1/4-20 Thumb) 16
115026 IT Code Towns (with N	115150 Drive Link, 13	115256 Bracket - Left 9
Plata 1	115151 Detent Cam, 13	115257 Bar - Upper Front, 16
115027 SP Code Levens (with Name	115152 Disc, 13	115258 Bar - Upper Rear, 16
Plate) 14	115153 Eccentric, 13	115259 Plate - Right. 16
115028 CP Code Levers (with News	115154 Drive Link, 13	115260 Plate - Left. 16
Plate) 1/	115155 Spacer, 13	115261 Ball Bearing Plate, 13
115029 BL Code Levers (with Name	115156 Gear Hub, 13	115262 Guard (upper and Lower). 16
Plate).14	115157 Sall Bearing Plate, 13	115263 Bushing, 13
115030 FIG Code Levers (with Name	115150 Busning, 13	115264 Ball Bearing Plate, 13
Plate),14	115163 Vano Cutto 6	115266 Ball Bearing, 13
115031 LET Code Levers (with Name	115164 Vane Ston 6	115267 Counter Shaft, 13
Plate),14	115165 Spring Bracket 6	115260 Motor Plate 35
115032 (No Code)	115166 Vane #1.6	115270 Geen Hub - Contan 12
115066 A Name Plate, 14	115167 Vane #2.6	115273 Coop - 10m 13
115067 B Name Plate, 14	115168 Vene #3.6	11527/ Geer - 31m 12
115068 C Name Plate, 14	115169 Vane #4.6	115280 Name Plate 11
115069 D Name Plate, 14	115170 Vane #5.6	115281 Trip-Off Lever 11
115070 E Name Plate, 14	115171 Comb, 6	115282 Latch (with Post) 11
115071 F Name Plate, 14	115172 Comb,6	115284 Operating Lever 11
115072 G Name Plate,14	115173 Contact Lever, 7	115285 Bracket.11
11507) I Name Plate,14	115175 Pull Bar, 7	115286 Bracket, 11
115075 J Name Plate,14	115176 Bar, 5,6	115287 Bracket, 11
115076 K Name Plate 14	115177 Bail, 9	115288 Blocking Lever. 11.27
115077 L Name Plate 1	115176 Lock Lever, 5, 6	115289 Blocking Lever, 11
115078 M Name Plate. 14	115182 Obest 4 d	115291 Cross Braces, 16
115079 N Name Plate, 14	115183 Dreaks+ d	115293 Blocking Lever, 11,27
115080 O Name Plate, 1/4	115184 Cortest Der C 10	115294 Function Lever, 5, 6, 26
115081 P Name Plate. 14	115185 Cortest Chi-13 C	115295 Latching Lever, 11,27
115082 Q Name Plate, 14	115188 Spring 10	115296 Latching Lever, 11,27
115083 R Name Plate, 14	115190 Insulator 19	115200 marrian District
115084 S Name Plate, 14	115192 Spring. 19	115303 Procket D. T. 15
115085 T Name Plate, 14	115195 Bracket. 11	11530/ Procket I II 3d
115086 U Name Plate, 14	115197 Comb. 11	115305 Clamp - Dottom 21
115087 V Name Plate, 14	115198 Comb, 11	115306 Clamp - Middle 21
115088 W Name Plate, 14	115138 Link,9 115139 Bracket,10 115140 Ball Bearing Lock,13 115141 Screw (6-40 Shoulder),13 115142 Main Shaft,13 115143 Ratchet Hub,13 115145 Sleeve,13 115146 Drive Arm,13 115148 Disc,13 115149 Eccentric,13 115151 Detent Cam,13 115152 Disc,13 115153 Eccentric,13 115155 Spacer,13 115156 Gear Hub,13 115157 Ball Bearing Plate,13 115158 Bushing,13 115162 Bar,5 115163 Vane Guide,6 115164 Vane Stop,6 115165 Spring Bracket,6 115166 Vane #1,6 115167 Vane #2,6 115168 Vane #4,6 115170 Vane #5,6 115171 Comb,6 115172 Comb,6 115173 Contact Lever,7 115175 Pull Bar,7 115176 Bar,5,6 115177 Function Lever,5,26 115178 Lock Lever,5,6 115179 Function Lever,5,26 115182 Shaft,6,8 115183 Bracket,8 115185 Contact Bar,8,19 115185 Contact Bar,8,19 115185 Spring,19 115195 Bracket,11 115197 Comb,11 115198 Comb,11 115198 Comb,11 115197 Comb,11 115198 Comb,11 115197 Comb,11	115307 Clamp - Top. 21
LLOUSY & Namé Plate.14	116206 Took 11 00	125000 - 10p, 21
	110200 LOCK, 11,27	115308 Terminal Strip.21

	115459 Cross Bar, 23 115460 Bracket, 23 115462 Receptacle Container #1, 19 115463 Receptacle Container #2, 19 115464 Receptacle Container #3, 19 115465 Receptacle Container #4, 19 115466 Plate, 19 115468 Guard, 19 115471 Cord (Assem.), 22 115472 Cable, 37 115473 Cable, 32 115474 Cable - Distributor, 36 115475 Cable, 12 115476 Fuse Bracket, 29 115477 Cover, 18 115478 Spring, 39 115479 Motor Pad, 37 115481 Pad, 39 115481 Pad, 39 115482 Post, 38 115483 Bracket, 18 115485 Bracket, 18 115485 Bracket, 18 115487 Plate, 37 115490 Cover, 39 115491 Relay - Bottom, 29 115493 Plug, 19 115523 Base Plate, 35 115524 Gear Hub, 33, 35 115525 Fost, 32, 36 115526 Insulator, 32, 34 115528 Bracket, 34 115529 Screw (6-40 x 11/16), 32, 36, 37 115589 Washer - Cupped, 23 115590 Screw (10-32 x 1/2), 23 115591 Rut (8-32 Special), 1, 2, 4 115607 Side Frame - Right (with Bushing), 32, 33 115608 Side Frame - Left (with Bushing), 32, 33	
115310 Cord (Assem.),22	115459 Cross Bar, 23	116024 Strip - Right,1
115311 Cord (Assem.),22	115460 Bracket, 23	116028 Roller (Assem.) Left,1
115314 Insulating Strip, 18	115462 Receptacle Container #1,19	116030 Roller (Assem.) Right,1
115316 Stud, 21	115464 Pecentuale Container #2,19	116032 Door = Leader 2
11531/ Switch,1/	115465 Recentacle Container #4.19	116033 Guide (Assem.).2
115320 Can = Red.17.28	115466 Plate.19	116038 Side Cover,2
115322 Push Button, 17, 28	115467 Support Bar, 19	116053 Roller, 3, 18, 23, 24
115323 Push Button, 17, 28	115468 Guard, 19	116056 Bracket,1
115324 Knob, 17	115471 Cord (Assem.),22	116059 Plate, 3, 18, 24
115326 Relay (Assem.),20	115472 Cable, 37	116060 Bracket - Left,2
115328 Relay (Assem.),20	115473 Cable, 32	116061 Bracket - Right,1
115329 Relay (Assem.),20	115474 Cable - Distributor, 50	116083 Detent Spring 2
115332 Peley (Assem.) 20	115475 Fuse Bracket 29	116084AB Door (Gray Green
115333 Delayed Relay Timer (Assem.)	115477 Cover. 18	Wrinkle).1
18	115478 Spring. 39	116088AB Door (Gray Green
115335 Relay (Assem.),20	115479 Motor Pad, 37	Wrinkle),1
115336 Cable (Assem.), 11	115480 Plate, 23	116096 Stud, 1, 2
115342 Cord (Assem.), 22	115481 Pad, 39	116121 Latch,2
115343 Form Support, 18	115462 POST, 36	Trees Wrinkle)
115344 Form Support, 10	115484 Bracket 18	116126AB Hinged Door (Gray Green
115347 Cable. 18	115485 Bracket.19	"/rinkle),1
115348 Cable.18	115487 Plate, 37	116142 Stud, 3
115349 Cord (Assem.), 22	115490 Cover, 39	116144 Roller Mtg. Strip - Right,
115350 Toggle Switch, 30	115491 Relay - Bottom, 29	24
115351 Cable, 29	115493 Plug, 19	116145 Roller Mtg. Strip - Leit,
115352 Relay,29	115495 Cable, 50	116147 Bracket 3
115355 Relay, 49	115524 Cear Hub. 33. 35	116172 Separator. 2
115355 Push Key. 28	115525 Post. 32. 36	116173 Receptacle Plate, 2
115356 Push Key, 28	115526 Insulator, 32, 34	116180 Tape Platform, 24
115357 Cord (Assem.),31	115527 Mounting Block, 32, 34	116182 Rectifier Platform, 1
115358 Fuse - 1 Amp, 29	115528 Bracket, 34	116189 Cover,2
115360 Cord (Assem.),31	115529 Screw (6-40 x 11/16), 32, 36, 37	116191 Roller,)
115361 Jack Strip 1-10,4	115500 Serew (10-32 x 1/2).23	116458 Strike.1
115363 Plue 22 31	115593 Screw (10-32 Special).1.2	116783 Fuse Holder, 29
115364 Designation Strip (Assem.).4	115594 Nut (8-32 Special),2	116932 Cover, 28
115365 Cord (Assem.),31	115595 Nut (1/4-20 Special),1,2,4	117359 Bracket - Stop, 2
115366 Line Cord (Assem.), 22, 31	115607 Side Frame - Right (with	117450 A Code Lever (with Name
115367 Relay Plate, 30	Bushing), 32, 33	Plate), 14
115368 Bracket, 30 115369 Bracket, 30	115608 Side Frame - Left (With	.117451 B Code Lever (with Name
115369 Bracket, 30	115600 Com Sleave (Assem.) 33	117,52 C Code Lever (with Name
1153824R Control Unit Blank (Grav	115610 Base Plate.33	Plate),14
Green Wrinkle).23	115611 Armature, 32	117453 D Code Lever (with Name
115388 Cord (Assem.), 31	115614 Post, 32	Plate),14
115389 Cord (Assem.),31	115618 Slide - Left,2	117454 E Code Lever (with Name
115391 Bracket, 39	Bushing), 32, 33 115608 Side Frame - Left (with Bushing), 32, 33 115609 Cam Sleeve (Assem.), 33 115610 Base Plate, 33 115611 Armature, 32 115614 Post, 32 115618 Slide - Left, 2 115619 Slide - Right, 1 115900 Gear Hub, 37 115901 Gear Hub, 37 115901 Gear Hub, 37 115902 Gear - 36T, 37 115903 Guiding Strip, 37 115904 Connection Block, 38 115905 Bracket, 38 115906 Bracket, 38 115908 Shim010 Thick, 37 115909 Pinion - 8T, 40	117455 P Code Lever (with Name
115392 Shield, 39	115901 Gear Nub. 37	Plate).14
115394 Terminal Support.4	115902 Gear - 36T.37	117456 G Code Lever (with Mame
115395 Cover Plate, 38	115903 Guiding Strip, 37	Plate),14
115396 Cable,25	115904 Connection Block, 38	117457 H Code Lever (with Name
115397 Insulator, 25	115905 Bracket, 38	Piate),14
115398 Terminal Block (Assem.),4	115000 Shim - 010 Think 37	Plate 1.14
115399 Cable,4 115400 Cable,4	115909 Pinion = 8T.AO	117459 J Code Lever (with Name
115400 Cable, 4 115403 Bar, 13 115412 Screw (7/32-24 x 7/8), 16	115910 Post. 37	Plate), 14
115412 Screw (7/32-24 x 7/8),16	115911 Mounting Strip, 38	117460 K Code Lever (with Name
115413 Collar, 13	115905 Bracket, 38 115906 Bracket, 38 115908 Shim010 Thick, 37 115909 Pinion - 8T, 40 115910 Post, 37 115911 Mounting Strip, 38 115912 Mounting Strip, 38 115913 Shaft, 37 115914 Ball Bearing, 37 115915 Bearing, 37 115916 Motor Plate, 37 115920 Bearing Housing, 37 115952 Washer - Felt, 13 115953 Retaining Disc, 13 115955 Driving Disc, 13 115978 Spring, 7	Plate),14 117461 L Code Lever (with Name
115414 Shaft,9	115913 Shart,37	Plate),14
115415 Post, 10	115914 Baring, 37	117462 M Code Lever (with Name
115423 Plug, 19 115424 Screw (6-40 Shoulder), 9	115916 Motor Plate, 37	Plate),14
115425 Spacer, 11	115920 Bearing Housing, 37	117463 N Code Lever (with Mame
115426 Top Plate (with Knob and	115952 Washer - Felt,13	Plate),14
Pins),39	115953 Retaining Disc, 13	117464 O Code Lever (with Name
115430 Bracket, 33	115954 D18c,13	Plate),14 117465 P Code Lever (with Name
115431 Retainer, 33	115979 Oriving Disc,19	Plate),14
115432 Plug, 34	115997 Gear = 38T. 33. 35	117466 Q Code Lever (with Name
115434 Container. 34	115998 Gear - 35T, 37	Plate),14
115435 Bracket, 34	116004AB Panel Cover (Gray Green	117467 R Code Lever (with Name
115436 Bracket, 37	Wrinkle),4	Plate),14
115439 Plunger, 19	115953 Retaining Disc,13 115954 Disc,13 115955 Driving Disc,13 115978 Spring,7 115997 Gear - 38T,33,35 115998 Gear - 35T,37 116004AB Panel Cover (Gray Green wrinkle),4 116009 Strip,4 116011 Insulator,25 116012 Mounting Angle,25 116013 Bracket,25	117468 S Code Lever (with Name Plate), 14
115441 Filter (Assem.), 34	116011 Insulator, 47	117469 T Code Lever (with Name
115442 Filter (Assem.), 33 115443 Plate, 2	116012 Hodnting Angle, 25	Plate),14
115452 Spring - Right, 21, 25	116015 Panel Strip,2	117470 U Code Lever (with Name
115453 Spring - Left,21,25	116017 Shim016 Thick, 2	Plate), 14
115454 Screw (10-32 x 5/16),16	116015 Panel Strip,2 116017 Shim016 Thick,2 116020 Shim016 Thick,1 116021 Spacer.1	117471 V Code Lever (with Name
	anovan spaces ja	Plate),14 117472 W Code Lever (with Name
115455 Insulator,5 115456 Backstop,13 115457 Catch,3,18,23,24	116022 Strip - Left,2 116023 Screw (1/4-20 x 5/8),1,2	Plate),14
11747/ Cacch, 5, 10, 23, 24	2200x) 5026# (2/4-20 x //0/)x;*	,

117473 X Code Lever (with Name
Plate),14

117474 Y Code Lever (with Name
Plate),14

117475 Z Code Lever (with Name
Plate),14

117476 LF Code Lever (with Name
Plate),14

117477 SP Code Lever (with Name
Plate),14

117478 CR Code Lever (with Name
Plate),14

117479 BL Code Lever (with Name
Plate),14

117480 FIG Code Lever (with Name
Plate),14

117481 LET Code Lever (with Name
Plate),14

117573 Cable,20

117574 Cable,20

117575 Cable,20

117575 Cable,20

117589 Duct Adapter,1

117601 Shaft,28

117602 Serew (6-40 Shoulder),10

117603 Serew (6-40 Shoulder),6,7,10,13